# Sommers-Bausch Observatory 24" Telescope

# **Spectroscopy Manual**



### IMPORTANT: THIS MANUAL IS FOR REFERENCE ONLY. DO NOT OPERATE THE TELESCOPES WITHOUT ATTENDING AN OFFICIAL TRAINING SESSION.

# TROUBLESHOOTING STEPS

- Remote desktop session closed / crashed
  - Double click on the "Start Remote Desktop" icon on the desktop of the local computer.
- Telescope is not responding to slew commands
  - Ensure that the telescope is still connected to TheSky. Look for a status message explaining that the telescope is at its software limits. Finally, check if the telescope is in the hardware limits by checking if it is pointed very close to the horizon. In this case, you must call SBO staff.
- Telescope is not pointing at the correct objects
  - Use the "Find Home" command on the Sky View toolbar to return to home, then try to go back to your object. If the problem persists, contact SBO staff.
- Scorpius terminal is frozen or not appearing (Aux Computer)
  - If frozen, double click on the "ScorpiusForceQuit.sh" file on the desktop to run it.
  - If not appearing, double click on the "ScorpiusConnect.sh" to open the terminal.

# **GENERAL TELESCOPE USE**

- Telescope Status
- The status of the telescope can be found in the **[Telescope]** pane. The text will either be red or green. The possible telescope statuses are:
  - **Not Connected**: The computer is currently not communicating with the control system. You must press "Connect" on the Sky View Toolbar.
  - Tracking Off: The telescope is currently not following objects on the sky; the motors are not moving, slew to an object start tracking, if it does not press the [Turn Sidereal Tracking On] button in the toolbar.
  - **Not Homed**: The telescope has not been homed since being powered off. Press the **[Find Home]** button in the toolbar.
  - Tracking at ...: The telescope is tracking an object, usually (but not always) "sidereal rate".
  - Slewing to target: The telescope is currently moving to a new target.
  - **Parking**: The telescope is currently going to its park position (this is different than home).
  - **Parked**: The telescope is in the park position. It will not respond to slews until "Unpark" and "Find Home" are pressed again.
- Emergencies
  - Please be very familiar with these procedures before using the telescope.
  - Weather Emergencies (Sudden rain, snow, hail, or heavy winds)
    - Immediately work as a team to park and cover the telescope and close the dome slit as fast as possible, in parallel. Then continue the shutdown procedures as normal.
  - Movement Emergencies
    - If the telescope is ever behaving in an unsafe fashion, such as going to the hardware limits, PRESS THE RED STOP BUTTON ON THE LOWER CONTROL PANEL (HARD ENOUGH TO HEAR THE CLICK).

# Opening Procedure 24-Inch Telescope



Note: Please read each step in its entirety before executing the instructions in that step. Some steps have additional information that may affect how you complete the step, or additional warnings for things to look out for.

### Location: Control Room

#### 1. Checks and System Startup

- a) Before starting, check in with anyone who may be on the deck, so they know to be careful with lights, and to not bring visitors up to the dome. When they leave, they should completely lock up and close the building, but it never hurts to double check.
- b) Ensure the door to the rest of the observatory (with the card swipe) is closed.
- c) If desired, turn on the heater or chain open the catwalk door.
- d) <u>Verify that there are no keys present</u> on the control panel.

Note: These keys are used to control the hard limits of the telescope. This system prevents the telescope from turning itself over and destroying the mirror. Unauthorized use of these keys can result in damage to the telescope. Only SBO staff members are allowed to use these keys.

- e) <u>Turn on auxiliary computer</u> using the covered switch on the left of the telescope control panel. *Note these switches act like buttons and should not be forced to stay in the up position.* Put the covers back down to prevent accidental contact.
- f) On the telescope control panel, flip up the cover on the [Mode] switch and flip the switch into the upper, [Check], position. Leave the cover up.
- g) On the control panel, <u>press the green **[START]**</u> button to turn on the telescope. You must press hard enough to hear and feel a heavy click.
- h) On the control panel, verify the [Telescope Power] indicator is illuminated.
- On the control panel, <u>press and hold the [Test] button</u>. Verify the [Telescope Power] indicator is not illuminated, the Emergency Light is on, and the Warning Buzzer is sounding. Then, release the [Test] button.

If the **[Telescope Power]** indicator, **Emergency Light**, or **Warning Buzzer** do not behave as described above please press the **[STOP]** button immediately and contact SBO Staff for assistance. Failure to do so can put the telescope at risk of damage.

- j) On the control panel, <u>close the [Mode] switch cover</u>, which automatically moves the switch into the [Run] position.
- k) In the internet browser on the auxiliary computer, login to the observing session.
- I) Switch to the other tabs in the internet browser to check the <u>weather forecast</u> and <u>wind</u> <u>limits</u>.
- m) Turn on TCS computer using the covered switch on the left of the control panel.

### Location: Dome

### 2. Prepare and Cool Dome

- a) Turn on the [Dome Rotation Power] switch on the eastern wall.
- b) If low altitude observing (<30°) is required, rotate the dome to an accessible position, and <u>couple the lower door section to the slit</u> using the pins. Make sure the door is secure before operating. Remember that the slit will not allow observing near zenith if the lower door is attached. *Please do not attempt this unless you have been trained by SBO staff on this procedure.*

Note: Never operate the dome when there are people present on the mezzanine. Please do not attempt to move dome components by hand, and <u>do not touch</u> the orange strip that goes around the dome itself.

- c) Turn on the [Dome Slit Power] switch on the western wall.
- d) Turn the [Ventilation Fan Power] knob on the eastern wall to "High".
  i. The switches on either side of the knob should be on, turn them on if they are not.\
- e) Unplug and plug back in the blue cable on the back of the computer mounted on the bottom of the 24" tube, with the label on it that says, "Cable to be replugged"

### Location: Control Room

### 3. Open Dome and Setup Telescope and Instrumentation

- a) On the top monitor, press the [Full Screen] button in the bottom right corner.
- b) Open the slit by pressing the [Open] button on the iPad. If the iPad is not working correctly, open the slit and windows using the switches up on the mezzanine. Note: you must wait until the slit fully opens to open the windows. Never open the slit only part way, only all the way open or all the way closed. Once you open the slit do not turn on the white lights in the dome as it will interfere with observations on the observing deck.
- c) Open the dome windows using the iPad, you must wait for the slit to fully open.
- d) Open <u>TheSky</u> by clicking on the blue circle on the task bar with "64".
- e) Press "Ok" or wait for the time to expire.
- f) <u>Home the telescope</u> by pressing [Find Home] on the <u>TheSky's</u> toolbar. Allow the telescope to finish finding the home position, which will be signaled by the telescope status switching to "Tracking at sidereal rate".
- g) If saving slit view images is desired, in the [Camera] pane, click on [AutoSave...], then [Choose...], then [ASTR3520] in the navigation bar, and then select your team's name from the list. Press [Select Folder] and [Ok].
- f) Open [SharpCap] by clicking the icon in the task bar.
- g) In <u>SharpCap</u> click on the [Cameras] drop down menu and select [ZWO ASI461MM Pro].
- h) In the <u>SharpCap</u> menu bar click on [File] -> [SharpCap Settings] -> [Filenames], and press [Browse...] and select your team's folder. Press [Ok].
- i) In <u>SharpCap</u>, ensure the **[ASTR3520]** profile is selected in the top right corner, and press **[Load]**.
- j) In the <u>SharpCap</u> thermal controls tab, change the **[Target Temperature]** to <u>20°C BELOW</u> <u>ambient</u>, and no lower than <u>-20°C</u>. Only set the target temperature in multiples of 5°'s. (There is a temperature readout on the dome control iPad.) Please refer to the Data Acquisition section for instructions on how to manage the temperature of the camera.
- k) In <u>SharpCap</u> set the exposure time to 0.2s and leave <u>SharpCap</u> up on the screen.
- I) Turn on both <u>comparison lamps</u>, using the iPad.

- m) In <u>TheSky</u> start a continuous exposure series with the slit view camera.
  - i. Go to the [Camera] pane, then [Focus Tools] tab.
  - ii. Ensure [Take Photo Continuously] is checked.
  - iii. Set the [Exposure Time] to 0.05s.
  - iv. Press the [Take Photo] button.
- n) Ensure the <u>FITS Viewer</u> window is on the bottom right monitor.

### Location: Dome

#### 4. Uncover and Prepare the Telescope

- a) If needed: use the stepladder to <u>remove the 4" finder scope cover</u>. Store the cover out of the way, making sure the cover is upside down to prevent the accumulation of dust and debris.
- b) Using the stairs, climb up to the mezzanine and <u>remove the 24" primary cover</u> by supporting the bottom with one hand and gripping the handle with the other. *IMPORTANT: Pull the cover straight off to avoid damaging the focus mechanism*.
- c) <u>Remove the 6" guide scope cover</u>.
- d) Store the covers out of the way and upside down on the mezzanine.

#### 5. Collimate the Spectrograph

- a) Turn on both [Comparison Lamps], if you have not done so already.
- b) Slew to zenith using the hand controller.
- c) <u>Center the 6" guide scope</u> by turning the **[Translation Stage Knobs]** until *both* white "guide" labels are aligned.
- d) Pull the **[Selector Rod]** all the way out on the back of the guide scope to select guide mode.
- e) <u>Uncover the grating</u>, by pulling out on the round knob at the center of the grating angle adjustment knob and fold it over to one side.
- f) Move the **[Grating Tilt]** to the angle that you will be taking science at.
- g) Switch the selector knob to [Comparison Lamp], and switch to the 20-micron slit.
- h) Turn on the monitor next to the telescope.
- i) Click on the [Lightning Bolt] icon in the histogram tab in <u>SharpCap</u>.
- j) Zoom in on bright emission lines in <u>SharpCap</u> near the center of the image.
- k) Using the **[Collimation Knob]**, focus the spectrograph by turning the knob until the emission lines near the center of the image are as sharp as possible.
- I) Turn off the [Comparison Lamps], switch the selector knob back to [Sky].
- m) Turn off the [Ventilation Fan Power] knob to prevent seeing artifacts.
- n) <u>Turn off all extraneous light sources</u>, including the <u>monitor</u> in the dome (only the phone screen and skirt power light should be on). Close the curtain to the dome.
- o) (Location: Control Room) In <u>TheSky</u>, in the [Camera] pane, and [Focus Tools] tab press [Abort].

Note: From this point on, the dome should be in science collection mode. All extraneous ight sources should be off. Ventilation fans should be off. The curtain at the bottom of the stairs should be closed.

### Location: Control Room

### 6. Focus the Telescope

- a) <u>Slew to a star</u> between magnitude 5.5 and 6.5 either selecting the star in the sky view, then pressing **[Slew]** in the **[Telescope]** or **[Find]** panes. *This object should be somewhat nearby to your science target to ensure optimal focus.*
- b) In the [Camera] pane and [Focus Tools] tab, press [@Focus3].
- c) Set the **[Exposure Time]** to 0.5 seconds and **[Binning]** to 4x4.
- d) Press [Take Sample Photo] and wait for the image to download.
- e) Press the **[+ Magnifying Glass]** button until it says 1:1 in the top left corner of the @Focus3 window, and then center the brightest star.
- f) Press [Set Subframe to Current View].
- g) Press [Autofocus Now]. The system will now attempt to automatically focus the camera. This should take about 2 to 3 minutes. If it is having trouble, please use the legacy camera method.

### Legacy Focusing Method

- a) From the telescope home position, place the Bahtinov Mask on the telescope.
- b) <u>Slew to a star</u> between magnitude 0 and 3 either selecting the star in the sky view, or searching for it, then pressing **[Slew]** in the **[Telescope]** or **[Find]** panes. *This object should be somewhat nearby to your science target to ensure optimal focus.*
- c) In the **[Camera]** pane, and the **[Focus Tools]** tab, and set the **[Exposure Time]** to 1.0 seconds and **[Binning]** to 4x4. *Depending on the brightness of the star, you may need to adjust the exposure.*
- d) Uncheck [Take Photo Continuously]
- e) Press the [Take Photo] button.
- f) Click on the Subframe icon in the image window and then drag a box around the star (being sure to capture all the diffraction spikes.) (The Subframe checkbox should automatically turn on in the [Focus Tools] tab.)
- g) Check [Take Photo Continuously].
- h) Then press the [Take Photo] button.
- i) Using the [Focuser] pane, perform a Bahtinov focus for the telescope.
  - i. Move the focuser (using the **[Focuser]** pane) in steps of 2,500 counts, until the central diffraction spike evenly bisects the "X".
- j) <u>Stop the focus series</u> using the **[Abort]** button, in the **[Camera]** pane, <u>and uncheck</u> **[Subframe]**.
- k) Home the telescope and remove the Bahtinov Mask.

The telescope is now ready for taking data! Please refer to the "Data Acquisition" section of the manual for details on how to use the cameras/spectrograph.



# Data Acquisition 24-Inch Telescope



### Data Acquisition Procedure (Spectrograph Mode)

- 1. Set the [Grating Angle] and [Slit Width] to your desired settings.
- 2. Take a comparison image.
  - a. Switch the selector knob to [Comparison Lamp].
  - b. Turn on your desired [Comparison Lamp(s)].
  - c. Set the **[Exposure Time]** in <u>SharpCap</u> so the emission lines have a reasonable number of counts.
  - d. At the top-left of <u>SharpCap</u>, select [Start Capture], enter a [Target Name] to identify the comparison image, then select [Single Frame], and then [Start].
  - e. Turn off the [Comparison Lamps] and switch the selector knob back to [Sky].
- 3. In <u>TheSky</u> start a continuous exposure series with the slit view camera.
  - a. Go to the [Camera] pane, and [Focus Tools] tab.
  - b. Ensure [Take Photo Continuously] is checked.
  - c. Set the [Exposure Time] as needed to see your target. (0.5s is a good place to start)
  - d. Press the [Take Photo] button.
  - e. (To change the exposure time press [Abort] in the [Focus Tools] pane first.)
- 4. Slew to the target object and center the slit on the target. (You may rotate the spectrograph as needed.)
- 5. Set the [Exposure Time] as desired in <u>SharpCap</u>.
- 6. At the top-left of <u>SharpCap</u>, select [Start Capture], enter a [Target Name] to identify the science image, then select [Single Frame], and then [Start].
- 7. The exposure will begin, and its progress will be down at the bottom right of SharpCap.
- 8. Once you are done with your science images at a given grating angle and slit width, take an additional comparison image, using the same exposure time as the first comp. (repeat step 2).
- 9. Compare the two comparison images with DS9.
  - a. Open [DS9].
  - b. Click on [Frame] menu at the top and select [New Frame RGB].
  - c. Ensure **[Red]** is selected in the small popup window and open your initial comparison image in **[DS9]**.
  - d. Select [Blue] in the small popup window and open your final comparison image.
  - e. Zoom in on the emission lines, if the lines are entirely purple your comparison images are valid, if they have red and/or blue edges or there are a red set and blue set of lines the comparison images are invalid.
- 10. To take a dark frame, make sure that the dome is as dark as possible, and put the cover on the 24" and then take an exposure as normal (there is a drop-down target name for dark frames).
  - a. Because the ZWO ASI461 does not have a shutter, a dark frame is simply a normal frame with the surroundings as dark as possible.

# View the Slit and Decker Assembly in the Slit View (Spectrograph Mode)

- 1. Turn on the [Comparison Lamps].
- 2. In <u>TheSky</u> start a continuous exposure series with the slit view camera.
  - a. Go to the [Camera] pane, then [Focus Tools] tab.
  - b. Ensure [Take Photo Continuously] is checked.
  - c. Set the [Exposure Time] to 0.05s.
  - d. Press the [Take Photo] button.
- 3. Ensure the <u>FITS Viewer</u> window is on the bottom right monitor.
- 4. Switch the selector knob to [Comparison Lamp].
- 5. Turn on the monitor next to the telescope.
- 6. The slit and decker assembly will now be visible in the slit view.
- 7. Turn off the monitor next to the telescope.
- 8. Turn off the [Comparison Lamps], switch the selector knob back to [Sky].
- 9. In TheSky, in the [Camera] pane, and [Focus Tools] tab press [Abort].

### View the Sky in the Slit View (Spectrograph Mode)

- 1. Switch the selector knob to [Sky].
- 2. Turn off the [Comparison Lamps].
- 3. In <u>TheSky</u> start a continuous exposure series with the slit view camera.
  - a. Go to the [Camera] pane, then [Focus Tools] tab.
  - b. Ensure [Take Photo Continuously] is checked.
  - c. Set the [Exposure Time] as needed to see your target. (0.5s is a good place to start)
  - d. Press the [Take Photo] button.
  - e. (To change the exposure time press [Abort] in the [Focus Tools] pane first.)
- 4. The sky will now be visible in the slit view.

# CAMERA SETTINGS (Spectrograph Mode)

For the spectrograph, SharpCap is used to control the main camera (ZWO ASI461MM). Note that unlike TheSky, SharpCap takes exposures continuously, and an exposure explicitly for saving must be started.

### • Capture Profiles

- If you inadvertently change any settings and want to revert to default, select the **[ASTR3520]** profile and press **[Load]**.
- Camera Controls
  - All settings should be left at the Default, except for the **[Exposure]** setting, which controls exposure duration.

### Thermal Controls:

- The standard set-point for the camera is <u>20° C BELOW ambient</u>.
- Camera cooler power is displayed at the bottom center of the screen.
- If the camera cooler has stabilized at >75% power, you must raise your set-point until it can stabilize at or below 75% power. Raise the temperature by 5 Celsius at a time.

### • Display Histogram Stretch

- The dashed yellow lines can be moved with the mouse to change the stretch of the data.
- Pressing the lightning bolt applies a best guess stretch.

# CAMERA SETTINGS (TheSky)

- Camera Pane
  - The only two tabs in the camera pane that operators typically use are the "Take Photo" and "Focus Tools" tabs. They both have similar options.
  - Frame: This controls the frame type.
  - **Reduction**: Leave this at "None". The other options will produce images that are not suitable for science.
  - **Subframe**: Additional options for sub framing can be found in the "Size..." menu.
  - **Automatically save photos**: This will create a lot of data. It is fine to use this mode, but you must log each science quality image.
  - **Camera Pane**: Temperature Setup
    - The temperature setup can be found by pressing [Temp. Setup...] on the [Camera] pane.
    - The standard set-point for the camera is <u>20° C BELOW ambient</u>.
    - If the camera has stabilized at >75% power, you must raise your set-point until it can stabilize at or below 75% power. Raise the temperature by 5 Celsius at a time.

## FITS VIEWER (TheSky)

- The FITS Viewer Window will open as soon as an image is taken if the window is not already open.
- Under the [Photo] button is the menu for saving the image.
- The next button (looks like a graph), opens the stretch panel, where you can apply and adjust stretch functions to the image. In the bottom right corner select heuristic from the dropdown for DS9 like controls.
- The next three buttons control what mouse clicks do on the image.
- The last important button, which looks like a rectangle with a mouse cursor, is used to draw custom subframe sizes in the image, when **[Subframe]** is checked in the **[Camera]** pane.
- Finally, the [File Information] tab at the top allows you to view the FITS header.

# TELESCOPE MOVEMENT

- There are four ways that the telescope can be moved to point at a target:
  - Left Click in Sky View: This puts the selected object in the Find pane of TheSky, where you can check the object properties and issue slew commands.
  - Searching by Name: In the Find pane, search for the object you want. Make sure the object is listed in the Find pane as the selected object. Capitalization and whitespace do not matter in the search bar. Make sure to press the [Center] button in the Find pane to ensure that your object is inside the horizon limits.
  - Coordinates: If you know the RA/Dec coordinates of the object you want to look at, you can enter those by going to [Tools] → [Slew To Coordinates...] in the Telescope pane, and enter the position in the "Equatorial Coordinates" panel. Before Slewing, press [Center Chart on RA/Dec] to ensure that your object is inside the horizon limits, then press [Slew to RA/Dec].
  - **Manually**: Using the hand paddle on the telescope, you can manually move the telescope around the sky. Turning the knob on the paddle between the different numbers will change the rate at which the hand paddle moves the telescope.
- Additionally, there is the ability to stop tracking at any point by pressing **[Turn Tracking Off]** in the toolbar. This will stop the telescope from tracking the sky, which will cause trailing in the image.
  - Once the telescope has stopped tracking, you must either click on [Turn Sidereal Tracking On], in the toolbar, or slew to a new object to re-enable sidereal tracking rate.
- If the telescope is ever parked, it will not respond to any slew commands, or to manual move commands from the hand paddle or TheSky. The first step after the telescope is parked is to find home by pressing the **[Find Home]** button in the toolbar. This will unpark the telescope, as well as give it an accurate pointing model.
- Always remember to double check that your object is within the horizon limits to prevent a call to SBO staff to fix the telescope.
- IF AT ANY TIME THE TELESCOPE IS BEHAVING IN AN UNSAFE OR UNEXPECTED MANOR, HIT THE ABORT BUTTON IN TheSky VIEW TOOLBAR. IF THAT DOES NOT WORK, PRESS THE RED STOP BUTTON ON THE LOWER CONTROL PANEL.

# **TAKING FLATS**

- 1. To prepare to take dome flats, the telescope must be pointing at the flat field panel on the dome. This is accomplished in two steps:
  - a. Turn on the dome lights and <u>Park the telescope</u> by pressing the **[Park]** button in the toolbar. *Note: The telescope will move immediately after pressing the* **[Park]** button.
  - b. <u>Rotate the dome</u> back to home position, by lining the slit up with the "Dome" label, and centering the flat field panel in the circle in the status camera monitor.
- 2. <u>Turn on the flat field lamps</u> on the telescope (switches on the bottom labeled "WHITE SPOT"), and make sure all other light sources in the dome are off.
- 3. Proceed to take the flat fields just like any other light frame image but select the **[Frame]** type **[Flat Field]**. Aim for 20K-30K counts in the brightest part of the image (ignoring hot pixels).

Remember that you *can* also take sky flats, which avoids this procedure. The explanation for these flat types, however, is outside the scope of this manual.

# USING THE AUTOGUIDER

- Without using the autoguider, you are limited to exposures of 5 to 10 minutes (depending on the part of the sky being pointed at) before you start to notice smearing in the image. This is because of slight imperfections in the pointing and tracking accuracy of the telescope. With the autoguider running, you can boost your exposures to around an hour (perhaps higher, but it's best to take multiple exposures at that point).
- The autoguider on the 24" is a separate CMOS camera on the guide scope. The field of view of the guider is like the main *imaging* CMOS camera and should be aligned with the main telescope. Using the translation stage on the guide scope you can expand the area of sky available for guiding.
  - 1. Slew to your science target.
  - 2. (Location: Dome) Pull the [Selector Rod] on the back of the guide scope all the way out, and use the translation stage knobs to align the guide stickers.
  - 3. In the **[Autoguider]** pane, select the **[Focus Tools]** tab and set the **[Exposure Time]** to 1 second, verify that **[Subframe]** is unchecked, and **[Take Photo Continuously]** is checked.
  - 4. Press the **[Take Photo]** button, and make sure that there is a usable guide star (>2000 counts above background, the higher the better, but not saturated) in the field.
    - a. *(Location: Both)* You may need to take multiple photos while hunting around with the translation stage to find a usable guide star.
    - b. If you cannot find a bright enough star, increase the exposure time until you do. You should not need more than 10 seconds.
  - 5. (Location: Dome) Center the desired guide star by using the translation stage movements.
  - 6. In the [Focus Tools] tab, press [Abort].
  - 7. In the **[Autoguide]** tab, set the **[Exposure Time]** to the time you used in step 4, then press the **[Take Photo]** button.
  - 8. In the image, **double click** on the desired guide star. You should see a grey box flash around the guide star.
  - 9. <u>Press [Calibrate]</u> to enter the calibration routine and press [OK] to accept the default values. This should move the star up, down, left, right to calibrate how motor movements equate with star movements.
    - a. This may also fail if your guide star moves off the guider chip while calibrating (center the guide star better in the Guider FOV), if the star is saturated (reduce exposure time) or if the star is not far enough above the background (increase exposure time).
    - b. If this calibration fails, go back to step 7.
  - 10. After calibrating, press the **[Take Photo]** button to take an image of the current position of the guide star.
  - 11. Press the **[Autoguide]** button. The autoguider will start to take a series of images using a small frame centered on the selected guide star.
  - 12. Begin your science exposure in the [Camera] pane.
  - 13. Watch both the guider star image and the "Guide error" numbers in the [Autoguide] tab.
    - a. The star should remain in the center of the guide image, and the guide error numbers should stay within 10 pixels of zero. Additionally, you can press **[Graphs]** to bring up handy plots of the guiding error (use the mouse scroll bar to adjust all three graphs to range from -10 to 10 pix). If it stops guiding well, you will need to choose a new star to guide on.
  - 14. When you are done autoguiding, or if you are moving to a new object, simply <u>press [Abort]</u> in the [Autoguide] tab. <u>You must abort guiding before moving to a new object.</u>

# Closing Procedure 24-Inch Telescope



# **CLOSING PROCEDURE**

- 1. <u>Park the telescope</u> by pressing the **[Park]** button on the toolbar. Wait for the telescope to stop moving before proceeding.
- 2. <u>Return the dome to its home position</u> by rotating the dome until the slit is lined up with the yellow/black "dome" label, and the flat field panel is lined up with the circle in the telescope status cameras.
- 3. Close TheSky and SharpCap.
- 4. Shutdown the Windows 10 Telescope Control Computer in the remote session.
- 5. If you used the heater in the control room, <u>turn the heater off</u> by turning the knob counterclockwise.
- 6. Using the iPad, close the dome windows and dome slit.
- 7. (Location: Dome) Replace the telescope covers, for the 24" telescope, 6" guide scope, and 4" finder scope. The main cover should make a substantial click when it is properly in place.
- 8. Cover the grating by unfolding the lever on the grating adjustment knob and pushing it in.
- 9. <u>Power off the dome slit</u> by switching the [Dome Slit Power] switch to the off position.
- 10. If you observed at low altitudes and attached the lower door to the slit, <u>please detach the lower</u> <u>door</u> by moving the slit to over the mezzanine and following the proper procedure. Be sure to return the dome to its home position when you are done.
- 11. <u>Power off the dome rotation</u> by switching the **[Dome Rotation Power]** switch to the off position.
- 12. (Location: Control Room) Press the red **[STOP]** button on the Lower Control Panel. You will need to press hard enough to hear and feel a heavy click in the switch.
- 13. On the Auxiliary computer, <u>complete the logout form</u>, and close the browser. If there was an issue, either one you fixed yourself or called us for, please also <u>complete the problem form</u>.
- 14. If you logged into Scorpius, log out of Scorpius.
- 15. Shut down both computers.
- 16. If you opened the catwalk door, close and lock it now.
- 17. <u>Turn off the lights</u> in both the dome and the control room. Remember that the dome has two individual light switches, including the red stair lights.
- 18. For both the dome and control room: <u>stop, look, and listen</u>. There should be no strange sounds or lights coming from inside the dome, save for the phone. The control room should only have the clock and phone producing light.
- 19. If you are the last observers of the evening, please ensure that all the lights in the observatory are off, all doors closed, and all external doors should be locked. If you used the resource room to make coffee or food, please ensure that all appliances are off, and *please clean up after yourself. Remember: DON'T MAKE IT SOMEONE ELSE'S PROBLEM.*